



Compatible with...

9V products:

CD Box DC
CD Box DS2 T
CD Box S
CD Box S2
CD Box S3
Dock Box S Digital
MaiA CD
Media Box S
Remote Box S
Stream Box DS
Stream Box DS net
Bluetooth Box E
Bluetooth Box S
DAC Box S FL
DAC Box S USB
Switch Box S
Tuner Box S
USB Box S+

15V turntables:

all DC driven 15V Pro-Ject turntables

*NOT SUITABLE for the following turntables: X8, Xtension 9, Xten-sion 10, Xtension 12, RPM 9, RPM 10 and the models of Signature line, with high power consumption and a heavy, mass loaded, platter. For these turntables we recommend **Power Box RS2 Phono or Power Box RS Uni TT.**

18V products:

A/D Phono Box S
AD Box S2 Phono
BT Box E HD
DAC Box DS
DAC Box E
Dock Box S Fi
Head Box DS
Head Box S
Head Box S USB
Optical Box E Phono
Phono Box
Phono Box DS
Phono Box DS+
Phono Box DS2
Phono Box DS3 B
Phono Box DS2 USB
Phono Box E
Phono Box E BT
Phono Box E BT5
Phono Box MM
Phono Box S
Phono Box S2
Phono Box S3 B

Phono Box S2 Ultra
Phono Box ultra 500
Phono Box USB
Phono Box USB V
Pre Box S
Pre Box DS
Pre Box DS2 Analogue
Record Box E
Record Box USB
Speed Box S
Speed Box S2
CD Box DS
CD Box DS3
DAC Box DS2 Ultra
Head Box DS2 B
MaiA pre
Pre Box DS2 Digital
Speed Box DS
Stream Box S2 Ultra
Stream Box DS+
Tube Box DS
Tube Box Ds2
Tube Box S
Tube Box S2
Vinyl NRS Box S3

